



R15-4 EOC

HYDRAULIC EXCAVATOR

PARTS BOOKS



山东立派机械集团有限公司
Shandong Rippa Machinery Group Co., Ltd

📍 地址: 中国山东省济宁市任城区崇文大道2166号第六工业园A区
Add: Chengwen Avenue No. 2166 The sixth Industrial park Unit A, Jiesheng, Jining City Shandong Province, China

☎ 电话: 0537-2339712
Tel: 0537-2339712

📱 WhatsApp: +86 18753778717

✉ 电子邮箱: rippamachine@gmail.com

E-mail: rippamachine@gmail.com

🌐 网址: www.rippa.com

web: www.rippa.com



[2024 SECOND EDITION]

PARTS BOOK



R15-4 Eco

HYDRAULIC EXCAVATOR



[2024 (002) No

CONTENTS


No.	Description	Page
1.1	working device assembly.....	P1
1.2	bucket	P2
1.3	bucket cylinder assembly.....	P3
1.4	bucket rpd cylinder assembly.....	P4
1.5	arm cylinder assembly.....	P5
2.1	the appearance of the disassembly.....	p6
3.1	the internal assembly plate.....	p7
3.2	Power assembly.....	p8
3.3	Left armrest case assembly.....	p9
3.4	right armrest case assembly.....	p10
3.5	oil tank assembly.....	p11
3.6	Seat bracket assembly.....	P12
3.7	Articulated assembly.....	p13

3.8 Side sway cylinder assembly.....	p15
4.1 Telescopic lower assembly.....	p16
4.2 Push soil shovel assembly.....	P17
1.6 Bulldozer cylinder assembly.....	P18
1.8 .Telescopic cylinder assembly.....	p19
5. Excavator envelope diagram.....	P20
6.1 Bucket (auxiliary equipment)	p21
6.2 Mud hopper (auxiliary equipment)	p22
6.3 Inclined bucket (auxiliary equipment).....	p23
6.4 Rake (auxiliary equipment)	p24
6.5 Rotary drilling (auxiliary equipment)	p25
6.6 Change quickly (auxiliary equipment)	p26
6.7Wood gripper (auxiliary equipment)	p27

1.1 Working device assembly


REF NO.	Part NO.	Part Name	Q/TY	REMARKS
1	LP0107021140	The boom support is connected to the arm pin shaft	1	
2	LP0107021138	The boom support connects to the boom cylinder pin shaft	1	
3	LP0115010206	Move arm cylinder assembly	1	
4	LP0107020092	3099 Pin shaft	1	
5	LP0107020096	Pop cylinder pin shaft	1	
6	LP0115010207	Dock cylinder assembly	1	
7	LP0107021132	Boom connecting bucket rod pin shaft	1	
8	LP0107020097	Boom ear plate pin shaft	1	
9	LP0107020097	Boom ear plate pin shaft	1	
10	LP0115010208	Bucket cylinder assembly	1	
11	LP0112011037	dipper	1	
12	LP0115021277	Three-way ball valve assembly	2	
13	LP0115020229	A 3 / 8 quick connector	2	
14	LP0115030077	M14 quick connector	2	
15	LP0112012556	Shaker rod (with hole)	1	
16	LP0112013284	Rocker bar (without holes)	1	
17	LP0112012555	Casting connecting rod	1	
18	LP0107021005	Shake rod fixed shaft	1	
19	LP0107021006	Dig bucket pin shaft	2	
20	LP0107050036	Shaker fixing shaft (butter nozzle)	1	

Rippa R15 Parts Book Gardsman.se




21	LP0104011028	400mm bucket	1	
22	LP0112013016	swing arm	1	

1.2 bucket assembly




REF NO.	Part NO.	Part Name	Q/TY	REMARKS
1	LP0104011028	bucket assembly	1	
2	LP011109078	Side tooth	2	
3	LP0111080032	Frontal tooth	3	

1.3 Dig bucket cylinder assembly




REF NO.	Part NO.	Part Name	Q/TY	REMARKS
	LP0115010063	Bucket cylinder assembly	1	
1	LP0115010169	Shovel bucket cylinder rod	1	
2	LP0115010168	Shovel bucket cylinder block	1	
3	LP0116010092	Butter nozzle M10 * 1	2	
4	LP0112014165	Oil cylinder guard plate	1	
3	LP0116031360	Shovel bucket piston ring group	1	

1.4 Dock cylinder assembly



REF NO.	Part NO.	Part Name	Q/TY	REMARKS
	LP0115010062	Dock cylinder assembly	1	
1	LP0115010167	Dock cylinder rod	1	
2	LP0116010092	Butter mouth M10 * 1	2	
3	LP0115010166	Dock cylinder block	1	
4	LP0112014165	Oil cylinder guard plate	1	
5	LP0116031359	Pop piston ring group	1	

1.5 Move arm cylinder assembly




REF NO.	Part NO.	Part Name	Q/TY	REMARKS
	LP0115010061	Move arm cylinder assembly	1	
1	LP0115010165	Move arm cylinder rod	1	
2	LP0115010164	Move arm cylinder block	1	
3	LP0116010092	Butter mouth M10 * 1	2	
4	LP0112014166	Oil cylinder guard plate	1	
5	LP0116031358	Boom-piston sealing ring	1	

2.1 Upper disc appearance assembly


REF NO.	Part NO.	Part Name	Q/TY	REMARKS
1	LP0112013407	Heavy spray plastic	1	
2	LP0112012363	Pilot seat cover spray	1	
3	LP0112012337	Spray the pilot pedal	2	
4	LP0112012129	Left upper cover spray plastic	1	
5	LP0112012117	The lower left shield is sprayed with plastic	1	
6	LP0112010272	Seat articulated spray molding	1	
7	LP0112012494	Spray plastic on the seat fixing plate	1	
8	LP0112012493	Spray molding on the seat mounting plate	1	
9	LP0108040007	seat	1	
10	LP0112011954	Cover side plate spray plastic	1	
11	LP0112012360	The upper right guard is sprayed with plastic	2	
12	LP0108020070	Ceiling assembly	1	
13	LP0111080521	Rear view mirror	1	
14	LP0108020004	Ceiling cover	1	
15	LP0106020481	caution light	1	

16	LP0112012119	The lower right shield is sprayed with plastic	1	
17	LP0112013050	Rear cover spray plastic	1	




3.1 Upper disc internal assembly

a




REF NO.	Part NO.	Part Name	Q/TY	REMARKS
1	LP0119020187	Engine assembly	1	
2	LP0115030028	Expansion solenoid switching valve	1	
3	LP0106010004	storage battery	1	
4	LP0101030025	multiple unit valve	1	
5	LP0112012309	Lower left guard cover mounting plate	1	
6	LP0112013924	On the plate spray plastic	1	
7	LP0107021131	Move arm bracket pin shaft	1	
8	LP0112013016	Move the arm bracket	1	
9	LP0107021130	Front fork pin shaft of the deflection cylinder	1	
10	LP0102030001	rotary motor	1	
11	LP0115040010	Plastic diesel tank	1	
12	LP0115040073	Plastic hydraulic tank	1	
13	LP0112012072	Lower right guard cover mounting plate		
14	LP0112013922	Seat bracket assembly	1	
15	LP0104010883	Hydraulic quick-change solenoid valve	1	

3.2 power assembly




REF NO.	Part NO.	Part Name	Q/TY	REMARKS
1	LP0103020003	The Kubota D722 engine	1	
2		Engine mounting plate # 1	1	
3	LP0111020035	Engine shock absorber pad	4	
4	LP0110020012	radiator	1	
5	LP0113010022	Complete set of rubber hose	1	
6	LP0114010056	muffle	1	
7	LP0101010025	gear pump	1	
8	LP0102010037	bell housing	1	
9	LP0102010038	clutch	1	
10		Engine mounting plate 2	1	

3.3 New left armrest box assembly




REF NO.	Part NO.	Part Name	Q/TY	REMARKS
1	LP0106040042	Turn plate switch	1	
2	LP0111030063	Left armrest box	1	
3	LP0115030005	Lead left hand handle	1	
4	LP0116030472	Trumpet armrests	1	

3.4 New right armrest box assembly



REF NO.	Part NO.	Part Name	Q/TY	REMARKS
1	LP0115030006	Right lead handle	1	
2	LP0111030064	The right hand box	1	
3	LP0106040043	appearance	1	
4	LP0115030011	Push soil valve	1	
5	LP0116030472	Trumpet armrests	1	

3.5 Fuel tank assembly




REF NO.	Part NO.	Part Name	Q/TY	REMARKS
	LP0115040077	The NDI fuel tank assembly	1	
1	LP0115040010	Plastic diesel tank	1	
2	LP0111040007	Oil level sensor	1	
3	LP0107021028	Oil level sensor seat	1	
4	LP0111080091	Chai tank cover	1	
5	LP0112010264	Fuel tank fixing board	1	
6	LP0111080091	Hydraulic tank cover	1	
7	LP0115030046	Hydraulic oil return filter	1	
8	LP0115040073	Plastic hydraulic tank	1	
9	LP0112012646	Hydraulic fuel tank mounting plate	1	

3.6 Seat bracket assembly


REF NO.	Part NO.	Part Name	Q/TY	REMARKS
1	LP0112013101	Spray seat hing panel	1	
2		Diesel fuel element mounting plate	1	
3	LP0111020081	Electronic oil pump	1	
4	LP0112013093	Fuel tank protection plate spray molding	1	
5	LP0113010214	Engine intake trachea	1	
6	LP0111030064	Right armrest box assembly	1	
7	LP0111020090	Diesel filter element	1	
8	LP0111010005	air cleaner element	1	
9	LP0106040054	Power supply main switch	1	
10	LP0113010217	Air filter into the trachea	1	
11		The Kubota pilot filter element mounting plate	1	
12	LP0111020082	coating	1	
13	LP0115030049	Pilot filter	1	
14		Secondary kettle fixed card	1	
15	LP0111030063	Left armrest box assembly	1	
16	LP0111080035	Deputy kettle	1	

Rippa R15 Parts Book Gardsman.se


17	LP0111020089	Kubota oil and water separator	1	
18	LP0112013922	Seat bracket	1	



3.7 Articulate assembly




REF NO.	Part NO.	Part Name	Q/TY	REMARKS
1	LP0112012339	Multiplex valve installation board	1	
2	LP0101030025	multiple unit valve	1	
3	LP0111080081	foot plate	2	
4		Walking foot valve assembly	1	



REF No.	Part No.	Part Name	Q/TY	REMARKS
1	LP0111080348	NDI355 Walking pole purchase parts	1	
2	LP0111080202	15 either both pilot. 18 The three-cylinder. 20 has a tail. 30.30	1	
3	LP0115030052	NDI355 Double-pedal valve foot pedal	1	
4	LP0115030053	NDI355 Double-pedal valve connection plate	2	
5	LP0115030059	NDI355 Double coupling foot valve valve body procurement parts	1	


3.8 The deflection cylinder assembly



REF NO.	Part NO.	Part Name	Q/TY	REMARKS
1	LP0115010051	The deflected cylinder block	1	
2	LP0116030609	Complete deflection cylinder oil seal	1	
3	LP0115010156	The deflection cylinder cylinder rod	1	


REF NO.	Part NO.	Part Name	Q/TY	REMARKS
1	LP0115010086	telescopic cylinder	1	
2	LP011109555	Left walking bracket	1	
3	LP0102020023	Walking motor	2	
4	LP0102090005	Drive the chain wheel	2	
5		Walking motor mounting seat	2	
6	LP0102110003	rubber belt track	2	
7	LP0102060001	thrust wheel	4	
8	LP0107010455	pin roll	2	
9	LP0102070002	Mechanical tension device	2	
10	LP0102070016	Up tight rod	2	
11	LP0102050002	Central rotary joint	1	
12	LP0115010060	Push soil oil cylinder	1	
13	LP0112012652	Push soil shovel assembly	1	

4.1 Telescopic down chasis assembly




14	LP0102040001	Central rotary support	1	
15	LP0112013098	Butter mouth cover plate	2	
16	LP0112014135	Lower plate bracket	1	

4.2 Push soil shovel assembly




REF NO.	Part NO.	Part Name	Q/TY	REMARKS
1	LP0112012653	Expand the ear panel to the left side of the push shovel	1	
2	LP0112012652	dozer blade	1	
3	LP0112012654	Wide the ear panel to the right side of bulldozing	1	
4	LP0107020095	25X70 pin shaft	2	
5	LP0107020094	25X80 pin shaft	2	

4.3 Blade cylinder assembly




REF NO.	Part NO.	Part Name	Q/TY	REMARKS
	LP0115010060	Push soil shovel cylinder	1	
1	LP0115010151	Blade shovel cylinder block	1	
2	LP0112010831	Blade shovel cylinder plate spray	1	
3	LP0112010831	Stick for bulldozing cylinder	1	
4	LP0116030607	Complete set of bulldozing oil cylinder oil seal	1	

4.4 Expansion cylinder assembly



REF NO.	Part NO.	Part Name	Q/TY	REMARKS
	LP0115010086	telescopic cylinder	1	
1	LP0115010153	Expansion cylinder block	1	
2	LP0116030608	The complete set of telescopic oil cylinder oil seal	1	
3	LP0115010154	Retractable cylinder rod	1	


5. R15-3 (XD-JBT) envelope diagram



unit: mm

6 .R15-3 accessories (installation size: shaft diameter 25, gear spacing 92, shaft spacing 90)


6.1 R15-3 bucket



See 6.1 bucket for installation dimensions

REF No.	Size.	Part No.	Part Name
1	L=200mm	LP0104010778	200 Bucket
2	L=300mm	LP0104010928	300 Bucket
3	L=400mm	LP0104010980	400 Bucket
4	L=500mm	LP0104010774	500 Bucket
5	L=600mm	LP0104010775	600 Bucket
6	L=800mm	LP0104010781	800 Bucket
7	L=1000mm	LP0104010782	1000 Bucket
LP0107021006		Dig bucket fixed shaft	2

6.2 R15-3 mud bucket




See 6.1 bucket for installation dimensions

REF No.	Size.	Part No.	Part Name
1	L=250mm	LP0104010814	250 mud bucket (ramp)
2	L=300mm	LP0104010808	300 mud bucket (ramp)
3	L=400mm	LP0104010802	400 mud bucket (ramp)
4	L=500mm	LP0104010809	600 mud bucket (ramp)
5	L=600mm	LP0104010810	750 Mud bucket (ramp)
6	L=800mm	LP0104010811	800 mud bucket (ramp)
7	L=1000mm	LP0104010812	1000 mud bucket (ramp)

LP0107021006	Dig bucket fixed shaft	2
--------------	------------------------	---

6.3 R15-3 tilt bucket




REF No.	Size.	Number of cylinders	Part No.	名称 Part Name
1	L=600mm	1	LP0104010796	600 single cylinder tilt (ramp)
2	L=800mm	1	LP0104010797	800 single cylinder tilt (ramp)
3	L=1000mm	1	LP0104010798	1000 single cylinder tilt (ramp)
4	L=800mm	2	LP0104010799	800 double cylinder tilt (ramp)



See 6.1 bucket for installation dimensions

LP0107021006	Dig bucket fixed shaft	2
--------------	------------------------	---

6. 4 The R15-3 rakes




See 6.1 bucket for installation dimensions

REF No.	Size.	Part No.	Part Name
1	L=400mm	LP0104010784	400 Rake
2	L=500mm	LP0104010785	500 Rake
3	L=600mm	LP0104010786	600 Rake
4	L=800mm	LP0104010787	800 Rake
5	L=1000mm	LP0104010788	1000 Rake

LP0107021006	Dig bucket fixed shaft	2
--------------	------------------------	---

6. 5 R15-3 rotary dig drill



REF No.	Length.	Diameter	Part No.	Part Name
1	L=800mm	D=Ø15mm	LP0104010048	80cm long diameter 15cm rotary digging drill
2	L=800mm	D=Ø20mm	LP0104010053	80cm long diameter 20cm rotary digging drill
3	L=800mm	D=Ø30mm	LP0104010058	80cm long diameter 30cm rotary digging drill
4	L=800mm	D=Ø40mm	LP0104010063	80cm long diameter 40cm rotary digging drill
5	L=1000mm	D=Ø20mm	LP0104010182	100cm long diameter 30cm rotary digging drill
6	L=1000mm	D=Ø25mm	LP0104010711	100cm long diameter 25cm rotary digging drill
7	L=1000mm	D=Ø30mm	LP0104010190	100cm long diameter 30cm rotary digging drill
8	L=1200mm	D=Ø15mm	LP0104011145	120cm long diameter 15cm reducer rotary digging drill
9	L=1200mm	D=Ø20mm	LP0104010156	120cm long diameter 20cm rotary digging drill
10	L=1500mm	D=Ø10mm	LP0104010088	150cm long diameter 10cm reducer rotary digging drill
11	L=1500mm	D=Ø20mm	LP0104011091	150cm long diameter 20cm reducer rotary digging drill
			LP0107021006	Dig bucket fixed shaft
				2

See 6.1 bucket for installation dimensions

Rippa R15 Parts Book Gardsman.se

6.6 R15-3 Quick change




Figure 6.6.1 Hydraulic quick change





Figure 6.6.2 Mechanical quick change

REF No.	Part No.	Part Name
1	LP0104011406	Pilot hydraulic quick change
2	LP0104010233	Mechanical fast change

LP0107021006	Dig bucket fixed shaft	2
--------------	------------------------	---

6.7 R15-3 log grapple



REF No.	Part No.	Part Name
1	LP0104010837	Light wood grab two board
2	LP0104010477	Hydraulic rotary wood grip

LP0107021006	Dig bucket fixed shaft	2
--------------	------------------------	---